

Diversey

Oxivir[®] Tb and Oxivir[®] Tb Wipes

Ready to Use Surface Cleaner & Intermediate Disinfectant, General Virucide, Tuberculocide



A ready-to-use disinfectant cleaner based on proprietary hydrogen peroxide (AHP®) technology to deliver fast, effective cleaning performance.

Effective

- Formulated with proprietary hydrogen peroxide (AHP*) technology
- Meets Health Canada's standard for cleaning and decontaminating blood and body fluids
- Bactericidal, Tuberculocidal and Virucidal in one minute

Environmentally Responsible

- No VOC's, no added fragrance, no NPE's
- The active ingredient breaks down to water and oxygen

Easy-to-Use

- No rinsing is required in most applications for improved productivity
- Use to clean most hard, nonporous environmental surfaces with confidence
- Non-irritating to skin and eyes per Health Canada







Oxivir® Tb Ready to Use Surface Cleaner & Intermediate Level Disinfectant, General Virucide, Bactericide, Tuberculocide is a ready-to-use disinfectant cleaner based on proprietary hydrogen peroxide (AHP®) technology to deliver fast, effective cleaning performance. Oxivir® Tb Wipes is a one-step cleaner disinfectant wipe.

Use Directions

- Pre-clean heavily soiled areas.
- Apply solution by cloth or disposable wipe to hard, non-porous environmental surfaces.
- All surfaces must remain wet for one-minute to kill bacteria, HIV-1, HBV and HCV.
- Wipe surfaces dry, rinse or allow to air dry.
- Provides broad spectrum sanitizing of non-food contact surfaces in just 30 seconds. Not recommended for use on brass, copper, aluminum, bronze, granite, zinc or marble.
- Food contact surfaces require rinsing with potable water after disinfection.



Product Specifications

Description	
Color/Form	Colorless liquid / Colorless wipes
DIN Reg. No.	02283522 (RTU) 02283530 (Wipes)
рН	2.5–3.5
Scent	Characteristic
Specific Gravity	1.008 (RTU), 1.01 (Wipes)
Shelf Life	2 years (RTU), 3 year (Wipes)
Solubility	Complete

Hazard Rating

HMIS		NFPA
0	Health	0
0	Flammability	0
0	Reactivity	0

4=Very High; 3=High; 2=Moderate; 1=Slight; 0=Insignificant.

Available Items

Product Code	Description/Package Size	Dilution
4277293	12 x 32 fl. oz. / 946 mL Flip Top Bottles Plus Two Sprayheads	Ready-To-Use
5144708	12 x 160 count (6 x 7 in. Wipes) / 15.24 x 17.78 cm Canisters	Ready-To-Use
5627460	4 x 160 count (11 x 12 in. Wipes) / 27.9 x 30.5 cm Buckets	Ready-to-Use
5995422	12 x 60 count (7 x 8 in. Wipes) / 17.78 x 20.32 cm Canisters	Ready-to-Use
100823907	4 x 160 count (Refills) (11 x 12 in. Wipes) /27.9 x 30.5 cm	Ready-to-Use

Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available on-line at www.sealedair.com or by calling 888 352 2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, http://naextranet.diversey.com/dot/, for up to date shipping information.

AHP and Design® are registered trademarks of Virox Technologies, Inc. used under license.